Items to initialize

After reconnecting or performing maintenance on the battery, the following items must be initialized for normal system operation.

Item	When to initialize	Reference
Engine oil maintenance data (USA only)	After changing engine oil	P. 284
Tire pressure warning system	When the standard tire pressure changes by replacing tires or wheels	P. 298